

PEARSON YACHTS
OWNER'S GUIDE AND PROTECTION PLAN
PEARSON-26 ONE DESIGN

SECTION VIII: OUTBOARD ENGINE OPERATING INSTRUCTIONS

Pre-Start:

1. Read carefully and follow the procedures as outlined in the manufacturer's engine operating manual.
2. Check your fuel supply. Know the cruising radius your supply will allow.
3. Make sure the engine is securely clamped to the transom, and also secured to the boat by means of a chain or wire as a safety precaution.

Operation:

For proper operation of outboard refer to the manual provided by the engine manufacturer.